JetFlash®

User's Manual

(Version 3.0)

Table of Contents

Introduction

Congratulations on purchasing Transcend's **JetFlash®**. This handy little device lets you connect to any desktop or notebook computer with a USB port for fast, easy data transfer. The **JetFlash®** is completely plug-and-play, and has a large storage capacity as well as fast transfer rates, making it perfect for storing and transporting your files, folders, documents, photos and other personal digital content. In addition, the **JetFlash®**'s small convenient size, superior data retention and impressive appearance will provide you with a brand-new data storage experience.

Package Contents

The **JetFlash®** package includes the following items:

- JetFlash® USB Flash Drive
- Quick Start Guide
- Software CD (certain models)
- Lanyard, strap, or keyring accessory (refer to package for specific type)

Features

- Hi-Speed USB 2.0 compliant and backwards compatible with USB 1.0/1.1
- Vista compatible
- Supports Windows ReadyBoost®(Hi-Speed series)
- Easy Plug and Play installation
- Driverless
- Powered via the USB port. No external power or battery needed
- Includes useful data-management software

System Requirements

Desktop or notebook computer with a USB port and one of following operating systems:

- Windows® Me
- Windows® 2000
- Windows® XP
- Windows Vista®
- Windows® 7
- Mac® OS 9.0, or later
- Linux® Kernel 2.4.2, or later

Driver Installation

Driver Installation – Windows® Me, 2000, XP, 7 and Vista

No drivers are required. Newer Windows operating systems have built-in drivers that support the **JetFlash**®. Simply plug your **JetFlash**® into an available USB port and Windows will automatically install the files needed to use your device. A "**Removable Disk**" with a newly assigned drive letter will appear in the **My Computer** window.

Driver Installation – Mac® OS 9.0, or Later

No drivers are required. Just plug the **JetFlash**® into an available USB port and your computer will automatically detect it.

Driver Installation – Linux® Kernel 2.4.2, or Later

No drivers are required. Just plug the **JetFlash**® into the USB port and mount it.

Example:　　1.　First create a directory for the **JetFlash**®:

"**mkdir /mnt/jetflash**"

2.　Mount the **JetFlash**®:

"**mount –a –t msdos** /**dev/sda1** /**mnt/jetflash**"

Formatting the JetFlash® in Windows®

1. Plug the **JetFlash®** into an available USB port.

2. Open the "My Computer" window.

3. Right-click on the "Removable Disk" icon that represents the JetFlash®.

4. Select **"Format"** in the drop down menu.

> ⚠️ **WARNING! Formatting the disk will erase all of the data on your JetFlash®**

5. Click on the **"Start"** button and follow the on-screen instructions to format the **JetFlash®**.

Safely remove the JetFlash® from your Computer

Proper JetFlash® Removal – Windows® Me, 2000, XP, 7 and Vista

1. Click on the Removable Hardware icon ![icon] in the system tray.

2. The **"Safely Remove Hardware"** pop-up menu will appear. Select it to continue.

3. A message box will appear stating: "The 'USB Mass Storage Device' device can now be safely removed from the system."

4. Unplug the **JetFlash®** from your computer.

Proper JetFlash® removal – Mac® OS 9.0 or Later, Linux® Kernel 2.4.2 or Later

First drag the Disk icon that corresponds to your **JetFlash®** into the trashcan, then unplug your **JetFlash®** from the USB port.

> ⚠️ **WARNING! Improper removal of the JetFlash®, unstable system power, or system hang-ups / hard re-boots while data is being written to the JetFlash® may cause file corruption or permanent damage to the drive. The best way to prevent this is to avoid opening and continuously editing files directly from the JetFlash®. It is strongly recommended that you copy files from the JetFlash® to your hard disk first, then edit the files from the hard disk instead. Transfer the files back to the JetFlash® after editing.**